



RAFT

CONCRETE CARE

The following guide is to be used as a tool to aid in the upkeep of your product from Raft's Hutton Range.

- Use placemats or trivets under food items and coasters under beverages to prevent marks and stains.
- Avoid placing hot items directly on the concrete top. Concrete is heat resistant, but excessive heat can damage or discolour the sealer.
- Do not cut directly on the concrete top to avoid damaging the sealer. Always use a cutting board when preparing food.
- Clean up spills as soon as possible.
- Avoid abrasive soaps or cleansers. A mild soap and warm water is recommended for daily cleaning.
- When a heavier cleaning is needed, use a cleaner that is PH neutral. Avoid products containing bleach or ammonia.
- Keep furniture out of direct sunlight. Sunlight can alter finish colours and oxidise hardwoods.



RAFT

PEROBA CARE

The following guide is to be used as a tool to aid in the upkeep of your product from Raft's Hutton Range.

- Use a soft cloth for daily dusting and cleaning.
- Occasionally (as needed): Use a solution of warm distilled water and non-alkaline soap to work up a lather. The solution should be applied to the wood surface with a soft cloth once the area or surface is clean. Do not soak wood or leave standing liquids for a long period of time.
- Never use commercial cleaners, solvents, synthetic waxes, sprays or ammonia based cleaners on furniture.
- Protect wood surfaces from all heat and liquids. Use trivets, insulated pads, placemats and coasters appropriately.
- Keep furniture out of direct sunlight. Sunlight can alter finish colours and oxidise hardwoods.